






## Exposed Parts kit of Single Lever Basin Mixer Wall Mounted




## Temp & water pressure Requirement.


	Working Pressure: 1~3 bar
	Required Temperature: 5-65°C

- **Working Pressure:-**The water pressure should be Between 1 and 3 bar for proper functioning.
- **Required Temperature:-** The water temperature within the range of 5-65° for safe & effective use.
- **Note:-** These are recommended values for achieving conventional /Optimum output.




**Note:** THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL EXPOSED PART KIT OF SINGLE LEVER BASIN MIXER WALL MOUNTED WITHOUT WALL FLANGE.




**Note:** THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL EXPOSED PART KIT OF SINGLE LEVER BASIN MIXER WALL MOUNTED WITHOUT WALL FLANGE.



**Note:** THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL EXPOSED PART KIT OF SINGLE LEVER BASIN MIXER WALL MOUNTED WITHOUT WALL FLANGE.



### Steps & Cleaning agents requirements for Cleaning.



**Note:** THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL EXPOSED PART KIT OF SINGLE LEVER BASIN MIXER WALL MOUNTED WITHOUT WALL FLANGE.