






FLP-5053PM



TECHNICAL DRAWING



TEMP.& WATER PRESSURE REQUIREMENTS




Working Pressure: 1~3 bar



Required Temperature: 5-65°C

Note: Above are the recommended values for getting Conventional Output.





	<p>Apply soft cotton cloth</p>		<p>Apply soft cotton cloth</p>
<p>✗ DON'T</p>	<p>✗ DON'T</p> <p>Don't apply Scrub</p>	<p>Steps & Cleaning agents requirements for Aerator Cleaning.</p> <p>Aerator 1 hour Dip De-Scale Water Liquid Soap PH-5-7</p>	